


Instruction PowerStop Type A (app. 120 x 120 cm):

1. Cut shock cord rubber band in 70 cm length (4 pieces for each PowerStop).
2. In the 4 corners of the PowerStop; tie 1 shock cord rubber band in each eyelet.



3. Hang the PowerStop onto the wooden easels by 2 shock cords rubber band.



4. The PowerStop is to hang loosely.
5. The last 2 shock cord rubber band are to hang loosely around the cross batten for ensuring the PowerStop is in position also in windy weather.